

H&K International High Capacity Slide-In Refrigerator (HCPPT)

Weekly maintenance tasks

RF 08 W01 Clean Unit

Quarterly maintenance tasksRF 08 Q01 Clean Condenser
Coil & Check
Door Gasket**△ Hazards**


These icons alert you to a possible risk of personal injury.

▨ Equipment alerts

Look for this icon to find information about how to avoid damaging the equipment while doing a procedure.

★ Tips

Look for this icon to find helpful tips about how to do a procedure.

Why	The unit must be cleaned weekly to ensure proper operation.	
Time required	5 minutes to prepare	15 minutes to complete
Time of day	Evening after closing	For 24-hour restaurants: during slow period
Hazard icons	 Electricity	

Tools and supplies



Clean Towel

Procedure

- 1 Turn off unit
Press and hold right lower button of controller for 5 seconds to turn off the unit.



- 5 Turn on unit
Press and hold right lower button of controller for 5 seconds to turn on the unit. Allow to reach operating temperature.



- 2 Remove items from unit
Place remaining items into walk-in cooler while cleaning unit.



- 6 Re-fill unit with products
Re-fill the unit with the items from the walk-in cooler.



- 3 Remove interior wire shelves
Wash in sink with mild soap and sanitize with a solution of McD Sanitizer (HCS). Allow accessories to air dry.




- 4 Wipe down unit
Wipe down inside and outside of unit with a towel and sanitizing solution. Clean doors.



Why The condenser coil must be cleaned regularly to ensure the unit operates at peak performance. The door gasket condition must be checked to ensure the unit is sealed properly. Failure to do so could result in food product quality risks, premature refrigeration failure, additional energy usage, and voiding of warranty.

Time required 10 minutes to prepare 15 minutes to complete
Time of day Evening after closing For 24-hour restaurants: during slow period

Hazard icons  Electricity

Tools and supplies Soft bristled brush 


Procedure

1 Turn off unit
 Press and hold right lower button of controller for 5 seconds to turn off the unit.

 Electricity



4 Replace louvered panel
 Reinstall panel by aligning tabs with slots on each side of condenser housing. Push panel in and down until secure.

 **Tip**
 Make sure to check that the panel is tightly secured.




2 Remove louvered panel
 Lift panel up to clear tabs at each side of panel.



5 Check door gaskets
 Check to see if door gasket is broken. If the door gasket is broken, and cannot seal the cabinet properly, please call **800-521-3987** to order replacement gasket.



3 Clean Condenser Coil
 Using a soft bristled brush remove any dirt present on the coil.

 **Tip**
 Make sure to brush with the direction of the fins.



6 Turn on unit
 Press and hold right lower button of controller for 5 seconds to turn on the unit.

 Electricity

